

Pure Copper

1685

Grinding

	Steps	 PG	 FG	 FG	 FG
Surface 	Type	SiC Foil #320	SiC Foil #800	SiC Foil #1200	SiC Foil #4000
	Disc speed (rpm)	300	150	300	300
Abrasive 	Type				
	Predosing/dosing				
Lubricant 	Type	Water	Water	Water	Water
	Predosing/dosing				
	Force (N)	25	25	25	25
	Holder direction	>>	>>	>>	>>
	Holder speed (rpm)	150	150	150	150
	Time (min)	1	1	1	1

Polishing

	Steps	 DP	 OP
Surface 	Type	MD-Mol	MD-Chem
	Disc speed (rpm)	150	150
Abrasive 	Type	DP-Susp. P 3 µm	OP-S, 0.25 µm
	Predosing/dosing	3/6	1/10
Lubricant 	Type	DP-Red	
	Predosing/dosing	3/12	
	Force (N)	25	15
	Holder direction	>>	><
	Holder speed (rpm)	150	150
	Time (min)	5	1

Method comments

The method is developed to fit a standard equipment configuration with 30 mm specimen on 300mm disc. Dosing levels are valid for following equipment: Tegramin, AbraPol and LaboPol

For advice on how to adjust the method to fit your equipment, please take a look at Preparation Parameters.

The preparation time for the plane grinding (PG) step depends very much on the condition of the samples and if they are prepared as single specimens or clamped in a specimen holder. Please check the samples after the first step and repeat it if necessary.

Take a look at Preparation Parameters [➤](#)